



1. **Set Screw.** Using a high impact driver with the Klear setting tool, drive the fastener perpendicular to the preset level below the trim or deck surface.
2. **Set Plug.** Place plug into hole with surface side up and gently tap with a smooth hammer until it is flush. Ensure that hammer head is parallel to surface to avoid marring. **All Set!**

IMPORTANT INFORMATION

- The Klear setting tool must be used to set the Cortex screw at the correct depth.
- Under some conditions, you may see a subtle indication that there is a doweled plug in the trim or decking. It is recommended that you test the Cortex system on a few boards to ensure you approve of the final look.
- To meet Cortex warranty requirements, see Klear Trimboard Installation Guidelines at kleerlumber.com